
wiring cupboard bracket

Install the Internet-Box 3 in the wiring cupboard

(Deutsch auf der Rückseite)








Installation example

Network connection in one room

Unscrew the stand of the


Install the two mounting brackets and hang the Internet-Box in the wiring cupboard.




Optional: Use the enclosed screws to fix the bracket

and the fibre optic cable ...

Connect the power supply




... or the DSL cable.



Please refer to the Internet-Box instructions for help.

Connect the network ports with the Internet-Box.



The ports in the wiring cupboard correspond to the network ports in your rooms (same number). You can connect devices to the Internet via cables there.

For more information see www.swisscom.ch/ home-networking




Your Internet-Box is now fully installed.

Optional: Connect a corded telephone to the Internet-Box.






Connect the phone to a network port. Use the telephone cable to connect the «phone» port on the Internet-Box to the corresponding network port.



HD-Phones connect to the Internet-Box, even when they are in the wiring cupboard. If the distance is too great, you can use a DECT repeater, available in the online shop as «Gigaset Repeater HX».



Wiring cupboard



Note: WLAN and DECT reception is greatly impaired in the wiring cupboard. To improve WLAN performance, we recommend connecting a WLAN-Box 2 in a central room. More information on the WLAN-Box: swisscom.ch/wlan-box2